

Button Catch Fitting Instructions

This button catch is designed for boxes with a minimum wall thickness of 12.5mm.

Best results are achieved by using a drill press. Fit and check hinges **before** fitting the catch. A very small dab of adhesive (superglue or epoxy resin) is recommended to secure the fittings.

